


PARTS LIST

MOROOKA

MST-2500

RUBBER CRAWLER CARRIER

Serial No. 25134 and up



PARTS LIST

MST-2500

Serial No. 25134 and up

FOREWORD

When ordering a part, please specify the model number, the engine serial number and the reading of the service meter.

For complete understanding, the parts list is written as follows:

Fig. number	Figure numbers are not continuous.
Description	"•" is put in front of the name of an assembly component and the item is entered next to the assembly. If a part marked with "•" is an assembly, its component is marked with "••".
Quantity	The number of pieces per set used for assembly is specified. For assembly or part group components, the number of pieces per assembly is specified.
Serial number	The engine or machine serial number in which the part is used.
Codes	The codes and part numbers specified in the "Part No." and "Part Name" columns represent the following: ☐ The part specified in the line above is applicable instead of this part. ☐ Part supplied as semi-finished. It must be reworked before use. ☐ Supplied as a set rather than singly.

CONTENTS

	FIG NO.	PAGE
ENGINE RELATED PARTS	101	0-2
AIR INTAKE AND EXHAUST RELATED PARTS	111	0-6
FUEL TANK AND PIPING	121	0-10
FRAME RELATED PARTS	201	0-12
UNDER CARRIAGE RELATED PARTS	301	0-16
TRACK ROLLER AND CARRIER ROLLER	311	0-18
STEERING CONTROL SYSTEM (1/2)	401	0-22
STEERING CONTROL SYSTEM (2/2)	402	0-24
ENGINE CONTROL SYSTEM	411	0-28
HYDRAULIC PIPING (1/4)	501	0-30
HYDRAULIC PIPING (2/4)	502	0-34
HYDRAULIC PIPING (3/4) (SERIAL NO.25134—25186)	503	0-38
HYDRAULIC PIPING (3/4) (SERIAL NO.25187—25241)	503A	0-42
HYDRAULIC PIPING (3/4) (SERIAL NO.25242—)	503B	0-46
HYDRAULIC PIPING (4/4)	504	0-50
HYDRAULIC OIL TANK (SERIAL NO.25134—25217)	551	0-52
HYDRAULIC OIL TANK (SERIAL NO.25218—)	551A	0-54
HYDRAULIC OIL FILTER	555	0-56
DUMP BODY RELATED PARTS	601	0-58
INSTRUMENT PANEL (SERIAL NO.25134—25241)	701	0-60
INSTRUMENT PANEL (SERIAL NO.25242—25267)	701A	0-64
INSTRUMENT PANEL (SERIAL NO.25268—)	701B	0-66
ELECTRICAL SYSTEM (SERIAL NO.25134—25267)	711	0-68
ELECTRICAL SYSTEM (SERIAL NO.25268—)	711A	0-72
BATTERY (SERIAL NO.25134—25267)	715	0-76
BATTERY AND BATTERY RELAY (SERIAL NO.25268—)	715A	0-78
MARKS AND PLATES	811	0-82
TOOL	901	0-84
NUMERICAL INDEX		1

FIG. 101 ENGINE RELATED PARTS




FIG NO. 101

INDEX NO.	PART NO.	DESCRIPTION	Q'TY	SERIAL NO. MST-2500	SERIAL NO.
1	1-18110-1110	CUSHION	4	25134-	
2	0-1000-31235	BOLT	8	25134-	
3	0-1200-01210	NUT	8	25134-	
4	0-1100-01230	WASHER, SPRING	8	25134-	
5	0-1120-01223	WASHER	8	25134-	
6	0-1200-01613	NUT	4	25134-	
7	0-1100-01640	WASHER, SPRING	4	25134-	
8	0-1120-01632	WASHER	4	25134-	
9	1-19140-0010	RADIATOR ASS'Y	1	25134-	
10	1-19140-1210	OIL COOLER ASS'Y	1	25134-	
11	1-19140-1410	BRACKET, L.H.	1	25134-	
12	1-19140-1420	BRACKET, R.H.	1	25134-	
13	0-1200-01008	NUT	6	25134-	
14	0-1100-01025	WASHER, SPRING	6	25134-	
15	0-1120-01020	WASHER	6	25134-	
16	0-1010-01020	BOLT	6	25134-	
17	0-1100-01025	WASHER, SPRING	6	25134-	
18	0-1120-01020	WASHER	6	25134-	
19	1-19140-1310	HOSE, INLET	1	25134-	
20	1-19140-1320	HOSE, OUTLET	1	25134-	
21	0-2710-00080	CLAMP	2	25134-	
21A	0-2710-00085	CLAMP	1	25134-	
21B	0-2710-00090	CLAMP	1	25134-	
22	1-11140-1330	CUSHION	4	25134-	
23	0-1000-01260	BOLT	4	25134-	
24	0-1120-01223	WASHER	8	25134-	
25	0-1200-01210	NUT	8	25134-	
26	1-19610-0010	HYDRAULIC PUMP ASS'Y	1	25134-	
27	1-19610-1310	.COUPLING	1	25134-	
28	1-19610-0020	.GEAR PUMP ASS'Y	1	25134-	

FIG NO. 101

INDEX NO.	PART NO.	DESCRIPTION	Q'TY	SERIAL NO. MST-2500	SERIAL NO.
29	0-2051-01826	.O-RING	1	25134-	
30	0-1000-31235	.BOLT	2	25134-	
31	0-1000-31245	.BOLT	2	25134-	
32	0-1100-01230	.WASHER, SPRING	4	25134-	
33	0-1120-01223	.WASHER	2	25134-	
34	1-19160-1110	COUPLING	1	25134-	
35	1-19160-1120	.BOLT	4	25134-	
36	1-19160-1160	BOLT	4	25134-	
37	1-19160-1130	BOSS	1	25134-	
38	1-19160-1140	PLATE, CENTER	1	25134-	
39	1-19160-1150	COVER	1	25134-	
40	0-1000-31030	BOLT	12	25134-	
41	0-1100-01025	WASHER, SPRING	12	25134-	
42	0-1021-31615	BOLT	2	25134-	
43	0-1100-01640	WASHER, SPRING	2	25134-	
44	0-1020-32045	BOLT	2	25134-	
45	0-1100-02051	WASHER, SPRING	2	25134-	
46	1-19610-1510	BRACKET	1	25134-	
47	1-14110-1110	CUSHION	1	25134-	
48	0-1200-01210	NUT	1	25134-	
49	0-1100-01230	WASHER, SPRING	1	25134-	
50	0-1000-01030	BOLT	2	25134-	
51	0-1200-01008	NUT	2	25134-	
52	0-1100-01025	WASHER, SPRING	2	25134-	

FIG. 111 AIR INTAKE AND EXHAUST RELATED PARTS




FIG NO. 111

INDEX NO.	PART NO.	DESCRIPTION	Q'TY	SERIAL NO. MST-2500	SERIAL NO.
1	1-19120-0010	AIR CLEANER ASS'Y	1	25134-	
	1-19120-1120	.ELEMENT	1	25134-	
2	0-5620-00000	INDICATOR, DUST	1	25134-	
3	0-1000-00825	BOLT	2	25134-	
4	0-1000-00820	BOLT	4	25134-	
5	0-1200-00806	NUT	6	25134-	
6	0-1100-00820	WASHER, SPRING	6	25134-	
7	0-1120-00816	WASHER	6	25134-	
8	1-19120-1320	HOSE, JOINT	2	25134-	
9	1-19120-1310	PIPE	1	25134-	
10	0-2700-10165	CLAMP	4	25134-	
11	1-19120-1340	PIPE	1	25134-	
12	1-19120-1350	HOSE, JOINT	1	25134-	
13	0-2700-10138	CLAMP	1	25134-	
14	0-2700-10095	CLAMP	1	25134-	
15	1-18130-1110	MUFFLER, EXHAUST	1	25134-	
16	1-18130-1140	.GASKET	1	25134-	
17	0-1000-01035	.BOLT	4	25134-	
18	0-1200-01008	.NUT	4	25134-	
19	0-1100-01025	.WASHER, SPRING	4	25134-	
20	1-19130-1120	PIPE, FRONT	1	25134-	
21	1-18130-1130	PIPE, TAIL	1	25134-	
22	1-18130-1150	CLAMP	1	25134-	
23	0-1000-01035	BOLT	1	25134-	
24	0-1200-01008	NUT	1	25134-	
25	0-1100-01025	WASHER, SPRING	1	25134-	
26	1-18130-1160	CLAMP	2	25134-	
27	0-1000-01450	BOLT	2	25134-	
28	0-1200-01411	NUT	2	25134-	
29	0-1120-01432	WASHER	2	25134-	

FIG NO. 111

INDEX NO.	PART NO.	DESCRIPTION	Q'TY	SERIAL NO. MST-2500	SERIAL NO.
30	1-19130-1230	SUPPORT	1	25134-	
31	0-1000-01030	BOLT	2	25134-	
32	0-1000-01040	BOLT	2	25134-	
33	0-1100-01025	WASHER, SPRING	4	25134-	
34	0-1120-01020	WASHER	4	25134-	

FIG. 121 FUEL TANK AND PIPING





FIG NO. 121

INDEX NO.	PART NO.	DESCRIPTION	Q'TY	SERIAL NO. MST-2500	SERIAL NO.
	1-19150-0011	FUEL TANK ASS'Y	1	25134-	
1	1-19150-1111	.TANK	1	25134-	
2	1-11150-1131	.STRAINER	1	25134-	
3	1-11150-1121	.CAP, WITH LOCK	1	25134-	
4	0-2150-01048	.TUBE, LEVEL	1	25134-	
5	0-2700-00012	.CLAMP	2	25134-	
6	0-4000-00400	.PLUG, DRAIN	1	25134-	
7	0-1000-01020	BOLT	10	25134-	
8	0-1100-01025	WASHER, SPRING	10	25134-	
9	0-1120-01020	WASHER	10	25134-	
10	0-2152-01060	TUBE, SUPPLY	1	25134-	
11	0-2151-01085	TUBE, RETURN	1	25134-	
12	0-2700-00012	CLAMP	4	25134-	
13	0-2720-02506	CLIP	2	25134-	
14	0-1200-00605	NUT	2	25134-	
15	0-1100-00615	WASHER, SPRING	2	25134-	
16	0-2830-02420	TUBE, SPIRAL	AR	25134-	
17	0-2800-00202	BAND	AR	25134-	
	0-2800-00383	BAND	AR	25134-	

FIG. 201 FRAME RELATED PARTS




INDEX NO.	PART NO.	DESCRIPTION	Q 'TY	SERIAL NO. MST-2500	SERIAL NO.
1	1-19510-1110	FRAME	1	25134-	
2	1-19520-1110	GRILLE	1	25134-	
3	0-1000-00820	BOLT	10	25134-	
4	0-1100-00820	WASHER, SPRING	10	25134-	
5	0-1120-00816	WASHER	10	25134-	
6	1-19520-1120	BUMPER	1	25134-	
7	0-1000-01225	BOLT	8	25134-	
8	0-1100-01230	WASHER, SPRING	8	25134-	
9	0-1120-01223	WASHER	8	25134-	
10	1-11520-1131	BOX, HEAD LAMP	2	25134-	
11	0-1000-00830	BOLT	8	25134-	
12	0-1100-00820	WASHER, SPRING	8	25134-	
13	1-19520-1180	COVER, UNDER	1	25134-	
14	0-1000-01025	BOLT	6	25134-	
15	0-1100-01025	WASHER, SPRING	6	25134-	
16	0-1120-01020	WASHER	6	25134-	
17	1-19520-1320	COVER, SIDE	1	25134-	
18	0-1000-01020	BOLT	6	25134-	
19	0-1100-01025	WASHER, SPRING	6	25134-	
20	0-1120-01020	WASHER	6	25134-	
21	1-12520-1320	COVER	2	25134-25135	
	1-12520-1321	COVER	2	25136-	
22	0-1000-00816	BOLT	4	25134-25135	
23	0-1100-00820	WASHER, SPRING	4	25134-25135	
24	1-19520-1330	COVER, VALVE	1	25134-	
25	0-1000-00825	BOLT	4	25134-	
26	0-1120-00816	WASHER	4	25134-	
27	0-1200-00806	NUT	4	25134-	
28	0-1100-00820	WASHER, SPRING	4	25134-	
29	1-19510-1230	STEP	2	25134-	

FIG NO. :201


INDEX NO.	PART NO.	DESCRIPTION	Q'TY	SERIAL NO. MST-2500	SERIAL NO.
30	0-1000-01225	BOLT	4	25134-	
31	0-1100-01230	WASHER, SPRING	4	25134-	
32	1-11510-1210	CAP	2	25134-	
33	0-1000-00616	BOLT	4	25134-	
34	0-1100-00615	WASHER, SPRING	4	25134-	
35	0-1120-00616	WASHER	4	25134-	
36	1-19510-1310	BLOCK, CUSHION	2	25134-	
37	0-1310-01080	SCREW	4	25134-	
38	1-19520-1220	MIRROR, REAR VIEW	2	25134-	
39	1-19520-1150	BONNET	1	25134-	
40	1-11520-1170	HANDLE	1	25134-	
41	0-1000-00816	BOLT	2	25134-	
42	0-1100-00820	WASHER, SPRING	2	25134-	
43	1-19520-1160	SUPPORT, AIR CLEANER	1	25134-	
44	0-1000-01235	BOLT	5	25134-	
45	0-1200-01210	NUT	6	25134-	
46	0-1100-01230	WASHER, SPRING	6	25134-	
47	0-1120-01223	WASHER	6	25134-	
49	1-19520-1170	COVER, BATTERY	1	25134-	
50	1-15540-0010	OPERATOR'S SEAT A.	1	25134-	
51	1-15540-1510	BASE	1	25134-	
52	0-1200-00806	NUT	4	25134-	
53	0-1120-00816	WASHER	4	25134-	
54	0-1000-00820	BOLT	4	25134-	
55	0-1120-00816	WASHER	4	25134-	
56	0-1200-00806	NUT	4	25134-	
57	0-1100-00820	WASHER, SPRING	4	25134-	

FIG. 301 UNDER CARRIAGE RELATED PARTS



INDEX NO.	PART NO.	DESCRIPTION	Q'TY	SERIAL NO. MST-2500	SERIAL NO.
1	1-19310-1110	TRACK RUBBER	2	25134-	
2	1-19630-0010	MOTOR ASS'Y, TRAVEL	2	25134-25186	
	1-19630-0011	MOTOR ASS'Y, TRAVEL	2	25187-	
3	0-1000-32060	BOLT	40	25134-	
4	0-1100-02051	WASHER, SPRING	40	25134-	
5	1-19320-1110	SPROCKET	2	25134-	
6	1-19320-2110 0-1000-32060	BOLT	32	25134-	
7	0-1100-02051	WASHER, SPRING	32	25134-	
	1-19330-0010	IDLER ASS'Y	2	25134-	
8	1-19330-1110	.IDLER	1	25134-	
9	1-19330-1120	.SHAFT	1	25134-	
10	0-2000-03155	.O-RING	2	25134-	
11	0-6003-00313	.BEARING	4	25134-	
12	0-3311-04020	.RING, SNAP	2	25134-	
	1-19330-0020	.FLOATING SEAL ASS'Y	2	25134-	
13	(1-19330-1130)	..RING, SEAL	2	25134-	
14	(1-19330-1140)	..O-RING	2	25134-	
15	1-19330-1150	.CAP	2	25134-	
16	0-3300-02062	.RING, SNAP	2	25134-	
17	1-19330-1240	HOLDER, SLIDE	2	25134-	
18	1-19330-1160	PLATE, LOCK	4	25134-	
19	0-1000-31440	BOLT	16	25134-	
20	0-1100-01435	WASHER, SPRING	16	25134-	
21	0-1200-33024	NUT	4	25134-	
22	0-1100-03075	WASHER, SPRING	4	25134-	
23	1-19330-1210	SPRING, RECOIL	2	25134-	
24	1-19330-1220	CYLINDER	2	25134-	
25	1-11330-1230	VALVE	2	25134-	

FIG. 311 TRACK ROLLER AND CARRIER ROLLER



MST-2500

INDEX NO.	PART NO.	DESCRIPTION	Q'TY	SERIAL NO. MST-2500	SERIAL NO.
	1-19340-0011	CARRIER ROLLER ASS'Y	4	25134-25161	
	1-19340-0012	CARRIER ROLLER ASS'Y	4	25162-	
1	1-19340-1110	.ROLLER,CARRIER	2	25134-25161	
	1-19340-1111	.ROLLER,CARRIER	2	25162-	
2	1-19340-1121	.SHAFT	1	25134-	
3	0-6000-06207	.BEARING	4	25134-	
4	0-3310-02572	.RING,SNAP	4	25134-	
	1-11330-0020	.FLOATING SEAL ASS'Y	2	25134-25161	
	1-12330-0020	.FLOATING SEAL ASS'Y	2	25162-	
5	(*1-11330-1130)	..RING,SEAL	2	25134-25161	
	(*1-12330-1130)	..RING,SEAL	2	25162-	
6	(*1-11330-1140)	..O-RING	2	25134-25161	
	(*1-12330-1140)	..O-RING	2	25162-	
7	1-11340-1130	.CAP	4	25134-25161	
	1-14340-1130	.CAP	4	25162-	
8	0-1350-00830	.SCREW	4	25134-25161	
	0-1350-00630	.SCREW	4	25162-	
9	1-11340-1140	.PLATE	2	25134-	
10	0-2000-03135	.O-RING	4	25134-	
11	0-1000-01025	.BOLT	4	25134-	
12	0-1100-01025	.WASHER,SPRING	4	25134-	
13	0-1000-00816	.BOLT	2	25134-	
14	0-1100-00820	.WASHER,SPRING	2	25134-	
15	0-1000-31225	BOLT	16	25134-	
16	0-1100-01230	WASHER,SPRING	16	25134-	
17	1-19350-1210	SHAFT,PIVOT	8	25134-25142	
	1-19350-1211	SHAFT,PIVOT	8	25143-	
18	1-19350-1230	BUSHING	32	25134-	
	1-19350-0010	TRACK ROLLER ASS'Y	16	25134-25142	
	1-19350-0011	TRACK ROLLER ASS'Y	16	25143-	

FIG NO. 311

INDEX NO.	PART NO.	DESCRIPTION	Q'TY	SERIAL NO. MST-2500	SERIAL NO.
19	1-19350-1110	.ROLLER, TRACK	1	25134-	
20	1-19350-1120	.SHAFT	1	25134-25142	
	1-19350-1121	.SHAFT	1	25143-	
21	0-6003-00210	.BEARING	4	25134-	
22	0-3310-03090	.RING, SNAP	2	25134-	
	1-17330-0020	.FLOATING SEAL ASS'Y	2	25134-	
23	(☆1-17330-1130)	..RING, SEAL	2	25134-	
24	(☆1-17330-1140)	..O-RING	2	25134-	
25	1-18350-1130	.CAP	2	25134-	
26	0-1350-01035	.SCREW	4	25134-	
27	0-2000-03150	.O-RING	2	25134-	
28	1-19350-1140	PLATE	16	25134-	
29	0-1200-33024	NUT	48	25134-25142	
	1-19350-1400	NUT	48	25143-	
30	0-1100-03075	WASHER, SPRING	48	25134-25142	
	0-1100-03690	WASHER, SPRING	48	25143-	
31	1-19350-1180	WASHER	48	25143-	
32	0-3400-00000	NIPPLE, GREASE	8	25134-	

FIG. 401 STEERING CONTROL SYSTEM (1/2)




FIG NO. 401

INDEX NO.	PART NO.	DESCRIPTION	Q 'TY	SERIAL NO. MST-2500	SERIAL NO.
1	1-12420-1110	LEVER	1	25134-	
2	1-12420-1120	KNOB	2	25134-	
3	0-1220-01006	NUT	2	25134-	
4	1-12420-1130	BOOT	1	25134-25135	
	1-12420-1131	BOOT	1	25136-	
5	0-3300-01218	RING, SNAP	1	25134-	
6	0-6110-00205	BLOCK, PILLOW	1	25134-	
7	1-12420-1140	ARM	1	25134-	
8	0-1242-02000	U-NUT	1	25134-	
9	0-1100-02051	WASHER, SPRING	1	25134-	
10	1-12420-1150	BRACKET, L.H.	1	25134-	
11	1-12420-1160	BRACKET, R.H.	1	25134-	
12	0-1000-01035	BOLT	4	25134-	
13	0-1200-01008	NUT	4	25134-	
14	0-1100-01025	WASHER, SPRING	4	25134-	
15	0-3011-01202	ROD	2	25134-	
16	0-3101-11200	END, ROD, L.H. THREAD	2	25134-	
17	0-1201-01210	NUT, L.H. THREAD	2	25134-	
18	0-1100-01230	WASHER, SPRING	2	25134-	
19	0-3100-11200	END, ROD	2	25134-	
20	0-1200-01210	NUT	2	25134-	
21	0-1100-01230	WASHER, SPRING	2	25134-	
22	0-1120-01223	WASHER	2	25134-	
23	0-1242-01200	U-NUT	4	25134-	
24	1-23420-1310	BRACKET	1	25134-	
25	0-1000-31060	BOLT, STOPPER	1	25134-	
26	0-1200-01008	NUT	1	25134-	
27	0-1000-00820	BOLT	2	25134-	
28	0-1200-00806	NUT	2	25134-	
29	0-1100-00820	WASHER, SPRING	2	25134-	

MST-2500

FIG. 402 STEERING CONTROL SYSTEM (2/2)




FIG NO. 402

INDEX NO.	PART NO.	DESCRIPTION	Q'TY	SERIAL NO. MST-2500	SERIAL NO.
1	1-19420-1210	SHAFT, OUTER	1	25134-	
2	0-3400-00170	NIPPLE, GREASE	1	25134-	
3	1-19420-1220	SHAFT, INNER	1	25134-	
4	1-12420-1230	LEVER	1	25134-	
5	0-3260-00663	PIN, TAPER	1	25134-	
6	1-12420-1250	LEVER, OUTER SHAFT	1	25134-	
7	1-12420-1260	LEVER, INNER SHAFT	1	25134-	
8	0-1360-00616	SCREW	2	25134-	
9	0-3260-00663	PIN, TAPER	1	25134-	
10	1-12420-1270	WASHER	1	25134-	
11	0-3300-01218	RING, SNAP	1	25134-	
12	0-6102-00204	BLOCK, PILLOW	1	25134-	
13	0-1000-01035	BOLT	2	25134-	
14	0-1100-01025	WASHER, SPRING	2	25134-	
15	0-1120-01020	WASHER	2	25134-	
16	0-6100-00206	BLOCK, PILLOW	1	25134-	
17	1-12420-1280	NIPPLE, GREASE	1	25134-	
18	0-1000-01255	BOLT	2	25134-	
19	0-1100-01230	WASHER, SPRING	2	25134-	
20	0-1120-01223	WASHER	2	25134-	
21	0-3000-01046	ROD	1	25134-	
22	0-3000-01072	ROD	1	25134-	
23	0-3100-11000	END, ROD	2	25134-	
24	0-1200-01008	NUT	4	25134-	
25	0-1100-01025	WASHER, SPRING	2	25134-	
26	0-3130-01060	BUCKLE, TURN	2	25134-	
27	0-3111-11000	END, ROD, L.H. THREAD	2	25134-	
28	0-1201-01008	NUT, L.H. THREAD	2	25134-	
29	0-1200-01008	NUT	2	25134-	
30	0-1100-01025	WASHER, SPRING	2	25134-	

FIG NO. :402

INDEX NO.	PART NO.	DESCRIPTION	Q 'TY	SERIAL NO. MST-2500	SERIAL NO.
31	0-3500-01020	COLLAR	2	25134-	
32	0-1000-01050	BOLT	2	25134-	
33	0-1220-01006	NUT	2	25134-	

FIG. 411 ENGINE CONTROL SYSTEM




FIG NO. 411

QTY	PART NO.	DESCRIPTION	QTY	SERIAL NO. MST-2500	SERIAL NO.
	1-12410-0010	LEVER ASS'Y, FUEL CONTROL	1	25134-	
1	1-12410-1110	.LEVER ASS'Y	1	25134-	
1	1-11410-1120	.KNOB	1	25134-	
1	1-17410-1120	CABLE	1	25134-	
1	1-11410-1210	JOINT ASS'Y	1	25134-	
2	0-1000-00820	BOLT	2	25134-	
2	0-1120-00816	WASHER	2	25134-	
2	0-1200-00806	NUT	2	25134-	
2	0-1100-00820	WASHER, SPRING	2	25134-	
1	1-19410-0020	LEVER ASS'Y, ENGINE STOP	1	25134-	
1	1-19410-1510	.LEVER ASS'Y	1	25134-	
1	1-11410-1610	.STOPPER	1	25134-	
1	1-19410-1310	BRACKET, CABLE	1	25134-	
3	0-1000-00816	BOLT	3	25134-	
3	0-1100-00820	WASHER, SPRING	3	25134-	
3	0-1120-00816	WASHER	3	25134-	

FIG. 501 HYDRAULIC PIPING (1/4)





FIG NO. 501

INDEX NO.	PART NO.	DESCRIPTION	QTY	SERIAL NO. MST-2500	SERIAL NO.
1	0-2102-01400	HOSE	1	25134-	
2	0-4220-01414	NIPPLE	2	25134-	
3	0-2700-10056	CLAMP	2	25134-	
4	0-4360-01414	ELBOW	2	25134-	
5	1-19670-1310	NIPPLE	1	25134-	
6	0-4200-01400	NIPPLE	1	25134-	
7	0-2252-00620	HOSE	1	25134-	
8	0-4320-00606	ELBOW	1	25134-	
	0-2010-03524	.O-RING	1	25134-	
9	1-19670-1340	ELBOW	1	25134-	
	0-2040-03027	.O-RING	1	25134-	
10	1-13670-1410	FLANGE	1	25134-	
11	0-2000-03135	O-RING	1	25134-	
12	0-1020-31025	BOLT	4	25134-	
13	1-19620-0011	CONTROL VALVE ASS'Y,DUMP	1	25134-	
	01-19620-0010	CONTROL VALVE ASS'Y,DUMP	1	25134-25217	
14	0-1000-01245	BOLT	4	25134-	
15	0-1120-01223	WASHER	4	25134-	
16	0-1200-01210	NUT	4	25134-	
17	0-1100-01230	WASHER, SPRING	4	25134-	
18	0-2253-00400	HOSE	2	25134-	
19	0-4300-00404	ELBOW	1	25134-	
20	0-4210-00404	NIPPLE	1	25134-	
21	1-19670-1330	ADAPTER	2	25134-	
	0-2040-03027	.O-RING	1	25134-	
22	0-4000-00400	PLUG	2	25134-	
23	1-18670-1320	TEE	2	25134-	
24	0-2250-00470	HOSE	2	25134-	
25	0-4300-00404	ELBOW	2	25134-	
26	0-2220-00655	HOSE	1	25134-	

INDEX NO.	PART NO.	DESCRIPTION	Q'TY	SERIAL NO. MST-2500	SERIAL NO.
27	1-19670-1320	ELBOW	1	25134-	
	0-2040-03027	.O-RING	1	25134-	
28	0-4210-00606	NIPPLE	1	25134-	
29	0-4400-00602	TEE	2	25134-	
30	0-4200-00600	NIPPLE	4	25134-	
31	0-4360-00606	ELBOW	2	25134-	
32	0-4100-01006	ADAPTER	2	25134-	
33	(1-19650-0010)	FILTER ASS'Y	1	25134-	
34	1-19620-0030	VALVE ASS'Y, CHARGE RELIEF	1	25134-	
35	1-19620-1310	CLAMP	2	25134-	
36	0-1200-01008	NUT	4	25134-	
37	0-1100-01025	WASHER, SPRING	4	25134-	
38	0-1120-01020	WASHER	4	25134-	
39	0-2220-00670	HOSE	1	25134-	
40	0-2221-00650	HOSE	1	25134-	
41	0-4210-00606	NIPPLE	2	25134-	
42	0-4300-00606	ELBOW	2	25134-	
43	0-4100-01006	ADAPTER	2	25134-	
44	0-4400-00604	TEE	1	25134-	
45	0-2220-00440	HOSE	1	25134-	
46	0-4210-00404	NIPPLE	4	25134-	
47	0-4100-00604	ADAPTER	1	25134-	
48	0-4360-00404	ELBOW	1	25134-	
49	0-4122-00404	ADAPTER	2	25134-	
50	0-2840-02020	SHEET, RUBBER	2	25134-	
51	0-2800-00383	BAND	6	25134-	

FIG. 502 HYDRAULIC PIPING (2/4)




INDEX NO.	PART NO.	DESCRIPTION	Q'TY	SERIAL NO. MST-2500	SERIAL NO.
1	0-2332-01212	HOSE	1	25134-	
2	0-2321-01272	HOSE	1	25134-25135	
3	0-2322-01205	HOSE	1	25136-	
4	0-2321-01272	HOSE	1	25134-	
5	0-2331-01281	HOSE	1	25134-	
6	0-2030-03538	O-RING	8	25134-	
7	0-2610-01259	FLANGE, SPLIT	16	25134-	
8	0-1000-31445	BOLT	16	25134-	
9	0-1000-31245	BOLT	16	25134-	
10	0-2221-00410	HOSE	1	25134-25186	
11	0-2221-00430	HOSE	1	25187-	
12	0-2220-00460	HOSE	1	25134-	
13	0-4300-00404	ELBOW	2	25134-	
14	0-4120-00404	ADAPTER	2	25187-	
15	0-4122-00404	ADAPTER	2	25134-	
16	0-2010-02418	O-RING	1	25134-	
17	0-2221-00410	HOSE	1	25134-25135	
18	0-2221-00420	HOSE	1	25136-	
19	0-4410-00404	TEE	2	25134-	
20	0-2220-00455	HOSE	1	25134-	
21	0-4310-00404	ELBOW	1	25134-	
22	0-4400-00404	TEE	1	25134-	
23	0-2220-00455	HOSE	1	25134-	
24	0-4300-00404	ELBOW	2	25134-	
25	0-4200-00400	NIPPLE	1	25134-	
26	0-4122-00604	ADAPTER	2	25134-	
27	0-2220-00440	HOSE	1	25134-	
28	0-4310-00404	ELBOW	1	25134-	
29	0-4400-00402	TEE	1	25134-	
30	0-4200-00400	NIPPLE	1	25134-	

FIG NO. :502

INDEX NO.	PART NO.	DESCRIPTION	Q'TY	SERIAL NO. MST-2500	SERIAL NO.
26	0-2840-02020	SHEET, RUBBER	4	25134-	
27	0-2800-00383	BAND	12	25134-	

MST-2500

FIG. 503 HYDRAULIC PIPING (3/4) (SERIAL NO. 25134-25186)



MST-2500

INDEX NO.	PART NO.	DESCRIPTION	Q'TY	SERIAL NO. MST-2500	SERIAL NO.
1	1-11620-0020	VALVE ASS'Y, BRAKE	1	25134-*	
2	0-2232-00200	HOSE	1	25134-25135	
	0-2231-00280	HOSE	1	25136-*	
3	0-2231-00210	HOSE	1	25134-25135	
	0-2231-00220	HOSE	1	25136-*	
4	0-2231-00210	HOSE	1	25134-25135	
	0-2231-00220	HOSE	1	25136-*	
5	0-2231-00230	HOSE	1	25134-25135	
	0-2231-00210	HOSE	1	25136-*	
6	0-2230-00270	HOSE	1	25134-*	
7	0-2231-00220	HOSE	1	25134-25135	
	0-2231-00250	HOSE	1	25136-*	
8	0-2232-00220	HOSE	1	25134-25135	
	0-2232-00225	HOSE	1	25136-*	
9	0-2230-00290	HOSE	1	25134-25186	
10	0-2231-00250	HOSE	1	25134-25186	
11	0-4300-00202	ELBOW	8	25134-25186	
12	0-4410-00202	TEE	4	25134-*	
13	0-4122-00402	ADAPTER	2	25134-25186	
	0-2010-02418	.O-RING	1	25134-25186	
14	0-2230-00240	HOSE	1	25134-*	
15	0-2230-00240	HOSE	1	25134-*	
16	0-4210-00202	NIPPLE	2	25134-*	
17	0-4122-00402	ADAPTER	2	25134-*	
	0-2010-02418	.O-RING	1	25134-*	
18	1-19620-0040	SOLENOID VALVE ASS'Y, H-L SPEED	1	25134-*	
19	0-1200-00605	NUT	2	25134-*	
20	0-1100-00615	WASHER, SPRING	2	25134-*	
21	0-1120-00616	WASHER	2	25134-*	
22	0-2230-00260	HOSE	1	25134-*	

FIG NO. 503

INDEX NO.	PART NO.	DESCRIPTION	Q 'TY	SERIAL NO. MST-2500	SERIAL NO.
23	0-2230-00290	HOSE	1	25134-★	
24	0-2231-00250	HOSE	1	25134-★	
25	0-4320-00202	ELBOW	3	25134-25186	
	0-2010-02411	O-RING	1	25134-25186	
26	0-4410-00202	TEE	1	25134-★	

FIG. 503A HYDRAULIC PIPING (3/4) (SERIAL NO. 25187-25241)




FIG NO. 503A

QTY	PART NO.	DESCRIPTION	QTY	SERIAL NO. MST-2500	SERIAL NO.
1	1-11620-0020	VALVE ASS'Y, BRAKE	1	25134-*	
1	0-2231-00280	HOSE	1	25136-*	
1	0-2231-00220	HOSE	1	25136-*	
4	0-2231-00220	HOSE	1	25136-*	
1	0-2231-00210	HOSE	1	25136-*	
1	0-2230-00270	HOSE	1	25134-*	
1	0-2231-00250	HOSE	1	25136-*	
1	0-2232-00225	HOSE	1	25136-*	
6	0-4300-00202	ELBOW	6	25134-*	
4	0-4410-00202	TEE	4	25134-*	
1	0-2230-00280	HOSE	1	25187-*	
1	0-2231-00220	HOSE	1	25187-*	
2	0-4320-00202	ELBOW	2	25187-*	
1	0-2230-00240	HOSE	1	25134-*	
1	0-2230-00240	HOSE	1	25134-*	
2	0-4210-00202	NIPPLE	2	25134-*	
2	0-4122-00402	ADAPTER	2	25134-*	
1	0-2010-02418	.O-RING	1	25134-*	
1	1-19620-0040	SOLENOID VALVE ASS'Y, H-L SPEED	1	25134-*	
2	0-1200-00605	NUT	2	25134-*	
2	0-1100-00615	WASHER, SPRING	2	25134-*	
2	0-1120-00615	WASHER	2	25134-*	
1	0-2230-00260	HOSE	1	25134-*	
1	0-4320-00202	ELBOW	1	25187-*	
1	0-2010-02411	.O-RING	1	25187-*	
1	0-4410-00202	TEE	1	25134-*	
1	0-2230-00290	HOSE	1	25134-*	
1	0-2231-00250	HOSE	1	25134-*	
2	0-4210-00202	NIPPLE	2	25187-*	
2	0-4122-00402	ADAPTER	2	25187-*	

FIG NO. :503A

INDEX NO.	PART NO.	DESCRIPTION	Q 'TY	SERIAL NO. MST-2500	SERIAL NO.
	0-2010-0241B	.O-RING	1	25187-*	

FIG. 503B HYDRAULIC PIPING (3/4) (SERIAL NO. 25242-)





FIG NO. 503B

INDEX NO.	PART NO.	DESCRIPTION	Q'TY	SERIAL NO. MST-2500	SERIAL NO.
1	1-11620-0020	VALVE ASS'Y, BRAKE	1	25134-	
2	0-2231-00280	HOSE	1	25136-	
3	0-2231-00220	HOSE	1	25136-	
4	0-2231-00220	HOSE	1	25136-	
5	0-2231-00210	HOSE	1	25136-	
6	0-2230-00270	HOSE	1	25134-	
7	0-2231-00250	HOSE	1	25136-	
8	0-2232-00225	HOSE	1	25136-	
9	0-4300-00202	ELBOW	5	25134-	
10	0-4410-00202	TEE	4	25134-	
11	0-4200-00200	NIPPLE	2	25242-	
12	0-4360-00202	ELBOW	1	25242-	
13	0-4400-00202	TEE	1	25242-	
14	0-4210-00202	NIPPLE	1	25242-	
15	0-2230-00280	HOSE	1	25187-	
16	0-2231-00220	HOSE	1	25187-	
17	0-4320-00202	ELBOW	2	25187-	
18	0-2230-00240	HOSE	1	25134-	
19	0-2230-00240	HOSE	1	25134-	
20	0-4210-00202	NIPPLE	2	25134-	
21	0-4122-00402	ADAPTER	2	25134-	
	0-2010-02418	.O-RING	1	25134-	
22	1-19620-0040	SOLENOID VALVE ASS'Y, H-L SPEED	1	25134-	
23	0-1200-00605	NUT	2	25134-	
24	0-1100-00615	WASHER, SPRING	2	25134-	
25	0-1120-00616	WASHER	2	25134-	
26	0-2230-00260	HOSE	1	25134-	
27	0-4320-00202	ELBOW	1	25187-	
	0-2010-02411	.O-RING	1	25187-	
28	0-4410-00202	TEE	1	25134-	

FIG NO. 503B

INDEX NO.	PART NO.	DESCRIPTION	Q'TY	SERIAL NO. MST-2500	SERIAL NO.
29	0-2230-00290	HOSE	1	25134-	
30	0-2231-00250	HOSE	1	25134-	
31	0-4210-00202	NIPPLE	2	25187-	
32	0-4122-00402	ADAPTER	2	25187-	
	0-2010-02418	.O-RING	1	25187-	

FIG. 504 HYDRAULIC PIPING (4/4)



INDEX NO.	PART NO.	DESCRIPTION	Q'TY	SERIAL NO. MST-2500	SERIAL NO.
1	0-2220-00640	HOSE	1	25134-	
2	0-2220-00680	HOSE	1	25134-25186	
	0-2221-00600	HOSE	1	25187-	
3	0-4320-00606	ELBOW	2	25134-	
	0-2010-03524	.O-RING	1	25134-	
4	0-4210-00606	NIPPLE	2	25134-	
5	0-4400-00606	TEE	1	25134-	
6	0-2221-00600	HOSE	1	25134-	
7	0-4310-00606	ELBOW	1	25134-	
8	0-4300-00606	ELBOW	1	25134-	
9	0-2102-01040	HOSE	1	25134-	
10	0-2102-01035	HOSE	1	25134-	
11	0-4220-01010	NIPPLE	4	25134-	
12	0-2700-10038	CLAMP	8	25134-	
13	0-4360-01010	ELBOW	3	25134-	
14	0-4370-01010	ELBOW	1	25134-	
15	0-4200-01000	NIPPLE	9	25134-	
16	0-4400-01006	TEE	3	25134-	
17	0-4400-01004	TEE	1	25134-	
18	0-4000-00400	PLUG	1	25134-	
19	1-17670-1210	CHECK VALVE ASS'Y	1	25134-	
20	0-2100-00645	HOSE	1	25134-	
21	0-4220-00606	NIPPLE	2	25134-	
22	0-2700-10032	CLAMP	2	25134-	

FIG. 551 HYDRAULIC OIL TANK (SERIAL NO. 25134-25217)




FIG NO. 551

INDEX NO.	PART NO.	DESCRIPTION	Q'TY	SERIAL NO. MST-2500	SERIAL NO.
	1-19660-0010	HYDRAULIC TANK ASS'Y	1	25134-25217	
1	1-19660-1110	.TANK	1	25134-25217	
2	1-19660-1230	.STRAINER	1	25134-*	
3	1-11660-1120	.COVER	1	25134-*	
4	1-11660-1130	.O-RING	1	25134-*	
5	0-1000-00816	.BOLT	8	25134-*	
6	0-1100-00820	.WASHER, SPRING	8	25134-*	
7	1-11660-1140	.BREATHER	1	25134-*	
8	1-11660-1150	.GASKET	1	25134-*	
9	1-11660-1220	.BOLT	3	25134-*	
10	1-11660-1170	.STRAINER	1	25134-*	
11	1-11660-1160	.CAP	1	25134-*	
	1-11660-0020	.GAUGE ASS'Y, OIL LEVEL	1	25134-*	
12	1-11660-1180	..GAUGE	1	25134-*	
13	1-11660-1190	..BOLT	2	25134-*	
14	1-11660-1210	..WASHER	4	25134-*	
15	0-4000-01000	.PLUG, DRAIN	1	25134-*	
16	0-1000-01020	BOLT	8	25134-*	
17	0-1100-01025	WASHER, SPRING	8	25134-*	
18	0-1120-01020	WASHER	8	25134-*	

FIG. 551A HYDRAULIC OIL TANK (SERIAL NO. 25218-)






FIG NO. 551A

INDEX NO.	PART NO.	DESCRIPTION	Q'TY	SERIAL NO. MST-2500	SERIAL NO.
	1-19660-0011	HYDRAULIC TANK ASS'Y	1	25218-	
1	1-25560-1111	.TANK	1	25218-	
2	1-19660-1230	.STRAINER	1	25134-	
3	1-11660-1120	.COVER	1	25134-	
4	1-11660-1130	.O-RING	1	25134-	
5	0-1000-00816	.BOLT	8	25134-	
6	0-1100-00820	.WASHER, SPRING	8	25134-	
7	1-11660-1140	.BREATHER	1	25134-	
8	1-11660-1150	.GASKET	1	25134-	
9	1-11660-1220	.BOLT	3	25134-	
10	1-11660-1170	.STRAINER	1	25134-	
11	1-11660-1160	.CAP	1	25134-	
	1-11660-0020	.GAUGE ASS'Y, OIL LEVEL	1	25134-	
12	1-11660-1180	..GAUGE	1	25134-	
13	1-11660-1190	..BOLT	2	25134-	
14	1-11660-1210	..WASHER	4	25134-	
15	0-4000-01000	.PLUG, DRAIN	1	25134-	
16	0-4000-01400	.PLUG	1	25218-	
17	0-4000-00300	.PLUG	1	25218-	
18	0-1000-01020	BOLT	8	25134-	
19	0-1100-01025	WASHER, SPRING	8	25134-	
20	0-1120-01020	WASHER	8	25134-	

FIG. 555 HYDRAULIC OIL FILTER



INDEX NO.	PART NO.	DESCRIPTION	Q'TY	SERIAL NO. MST-2500	SERIAL NO.
	1-19650-0010	FILTER ASS'Y	1	25134-	
1	(☆1-19650-1110)	.BASE	1	25134-	
2	1-11650-1160	.PLUG	1	25134-	
3	0-2010-02418	.O-RING	1	25134-	
4	0-2010-02414	.O-RING	1	25134-	
5	1-19650-1120	.ELEMENT	1	25134-	
6	0-2000-03150	.O-RING	1	25134-	
7	1-19650-1140	.BODY	1	25134-	
8	1-11650-1170	.PLUG,DRAIN	1	25134-	
9	0-2010-02414	.O-RING	1	25134-	
10	0-2031-03511	.O-RING	1	25134-	
11	0-1000-01025	BOLT	2	25134-	
12	0-1100-01025	WASHER,SPRING	2	25134-	
13	0-1120-01020	WASHER	2	25134-	

FIG. 601 DUMP BODY RELATED PARTS





FIG NO. 500

INDEX NO.	PART NO.	DESCRIPTION		SERIAL NO. MST-2500	SERIAL NO.
1	1-19710-1110	BODY, DUMP	1	25134-	
2	1-19710-1140	DOOR, REAR	1	25134-	
3	1-11710-1150	REFLECTOR	1	25134-	
4	1-19710-1160	PIN	1	25134-	
5	0-3400-00100	NIPPLE, GREASE	1	25134-	
6	0-1120-03660	WASHER	1	25134-	
7	0-3220-06363	PIN, COTTER	1	25134-	
8	1-19710-1310	PIN, HINGE	2	25134-	
9	0-3400-00100	NIPPLE, GREASE	1	25134-	
10	0-1001-31200	BOLT	1	25134-	
11	0-1200-31210	NUT	1	25134-	
12	0-1100-01230	WASHER, SPRING	1	25134-	
13	1-19710-1400	ROD ASS'Y	1	25134-	
14	1-18640-0010	DUMP CYLINDER ASS'Y	1	25134-	
15	1-18710-1320	PIN, CYLINDER	1	25134-	
16	0-3400-00100	NIPPLE, GREASE	2	25134-	
17	0-1000-01225	BOLT	2	25134-	
18	0-1100-01230	WASHER, SPRING	2	25134-	
19	1-18710-1330	PLATE	2	25134-	
20	0-1000-01225	BOLT	2	25134-	
21	0-1100-01230	WASHER, SPRING	2	25134-	
22	1-18710-1340	PIN, CYLINDER	2	25134-	
23	0-1000-01225	BOLT	4	25134-	
24	0-1100-01230	WASHER, SPRING	4	25134-	
25	1-23710-1610	PIN, SAFETY	1	25134-	
26	1-23710-1620	PIN	1	25134-	
27	1-23710-1630	PIN, SNAP	1	25134-	

FIG. 701 INSTRUMENT PANEL (SERIAL NO. 25134-25241)



INDEX NO.	PART NO.	DESCRIPTION	QTY	SERIAL NO. MST-2500	SERIAL NO.
1	1-19520-1381	PLATE	2	25134-*	
2	0-1000-00620	BOLT	4	25134-25241	
3	0-1100-00621	WASHER, SPRING	4	25134-25241	
4	0-1120-00615	WASHER	4	25134-25241	
	1-19210-1110	PANEL ASS'Y, INSTRUMENT	1	25134-25227	
	1-19210-1111	PANEL ASS'Y, INSTRUMENT	1	25228-25241	
5	1-11210-1110	PANEL, INSTRUMENT	1	25134-25241	
6	0-5220-01114	GAUGE, ENGINE OIL PRESSURE	1	25134-25227	
	0-5220-01114	GAUGE, ENGINE OIL PRESSURE	1	25228-*	
7	0-5170-02400	LAMP, PILOT	2	25134-*	
8	0-5430-00000	SWITCH, HORN	1	25134-*	
9	0-5200-03124	AMMETER	1	25134-25227	
	0-5200-70024	AMMETER	1	25228-*	
10	0-5240-20024	TACHOMETER	1	25134-*	
11	0-5230-00024	METER, HOUR	1	25134-*	
12	0-5210-10024	GAUGE, WATER TEMPERATURE	1	25134-25227	
	0-5210-70024	GAUGE, WATER TEMPERATURE	1	25228-*	
13	0-5160-02400	LAMP, ENGINE OIL CHARGE	1	25134-*	
14	0-5400-00000	SWITCH, STARTING	1	25134-*	
15	0-5610-02400	RESISTOR	1	25134-*	
16	0-5050-00015	FUSE, 15A	5	25134-*	
	0-5051-00000	HOLDER, FUSE	5	25134-*	
17	0-5420-00000	SWITCH, FLASHER	1	25134-*	
18	0-5410-02001	SWITCH, LIGHTING	1	25134-*	
	00-5410-02000	SWITCH, LIGHTING	1	25134-25180	
19	0-5160-02400	LAMP, HYDRAULIC OIL CHARGE	1	25134-*	
20	1-17210-1150	WIRING HARNESS	1	25134-*	
21	0-5050-00040	FUSE, 40A	1	25134-*	
22	0-1000-00620	BOLT	4	25134-*	
23	0-1100-00615	WASHER, SPRING	4	25134-*	

FIG NO. 701

INDEX NO.	PART NO.	DESCRIPTION	Q 'TY	SERIAL NO. MST-2500	SERIAL NO.
24	0-1120-00616	WASHER	4	25134-*	
25	0-5450-00000	SWITCH,H-L SPEED	1	25134-*	
26	0-5161-02400	LAMP,H-L SPEED	1	25134-*	
27	1-19210-1110	SWITCH,MAIN	1	25134-*	

FIG. 701A INSTRUMENT PANEL (SERIAL NO. 25242-25267)






FIG NO. 701A

INDEX NO.	PART NO.	DESCRIPTION	Q'TY	SERIAL NO. MST-2500	SERIAL NO.
1	1-19520-1350	PLATE	1	25134-25267	
2	0-1050-00820	BOLT	4	25242-*	
	1-19210-1102	PANEL ASS'Y, INSTRUMENT	1	25242-25267	
3	1-12210-1110	.PANEL, INSTRUMENT	1	25242-*	
4	0-5220-01024	.GAUGE, ENGINE OIL PRESSURE	1	25228-*	
5	0-5170-02400	.LAMP, PILOT	2	25134-*	
6	0-5430-00000	.SWITCH, HORN	1	25134-*	
7	0-5200-70024	.AMMETER	1	25228-*	
8	0-5240-20024	.TACHOMETER	1	25134-*	
9	0-5230-00024	.METER, HOUR	1	25134-*	
10	0-5190-02403	.LAMP INDICATOR, HST OIL TEMPERATURE	1	25242-*	
11	0-5180-02403	.LAMP, PARKING BRAKE	1	25242-*	
12	0-5210-70024	.GAUGE, WATER TEMPERATURE	1	25228-*	
13	0-5160-02400	.LAMP, ENGINE OIL CHARGE	1	25134-*	
14	0-5400-00000	.SWITCH, STARTING	1	25134-*	
15	0-5610-02400	.RESISTOR	1	25134-*	
16	0-5050-00015	.FUSE, 15A	5	25134-*	
	0-5051-00000	.HOLDER, FUSE	5	25134-*	
17	0-5420-00000	.SWITCH, FLASHER	1	25134-*	
18	0-5410-02001	.SWITCH, LIGHTING	1	25181-*	
19	0-5160-02400	.LAMP, HYDRAULIC OIL CHARGE	1	25134-*	
20	1-17210-1150	.WIRING HARNESS	1	25134-25267	
21	0-5050-00040	.FUSE, 40A	1	25134-*	
22	0-1000-00620	BOLT	4	25134-*	
23	0-1100-00615	WASHER, SPRING	4	25134-*	
24	0-1120-00616	WASHER	4	25134-*	
25	0-5450-00000	SWITCH, H-L SPEED	1	25134-*	
26	0-5161-02400	LAMP, H-L SPEED	1	25134-*	
27	1-19210-1110	SWITCH, MAIN	1	25134-25267	

FIG. 701B INSTRUMENT PANEL (SERIAL NO. 25268-)




View Z

FIG NO. 701E

INDEX NO.	PART NO.	DESCRIPTION	QTY	SERIAL NO. MST-2500	SERIAL NO.
1	1-19520-1351	PLATE	1	25268-	
2	0-1050-00820	BOLT	4	25242-	
	1-19210-1103	PANEL ASS'Y, INSTRUMENT	1	25268-	
3	1-12210-1110	.PANEL, INSTRUMENT	1	25242-	
4	0-5220-01024	.GAUGE, ENGINE OIL PRESSURE	1	25228-	
5	0-5170-02400	.LAMP, PILOT	2	25134-	
6	0-5430-00000	.SWITCH, HORN	1	25134-	
7	0-5200-70024	.AMMETER	1	25228-	
8	0-5240-20024	.TACHOMETER	1	25134-	
9	0-5230-00024	.METER, HOUR	1	25134-	
10	0-5190-02403	.LAMP INDICATOR, HST OIL TEMPERATURE	1	25242-	
11	0-5180-02403	.LAMP, PARKING BRAKE	1	25242-	
12	0-5210-70024	.GAUGE, WATER TEMPERATURE	1	25228-	
13	0-5160-02400	.LAMP, ENGINE OIL CHARGE	1	25134-	
14	0-5400-00000	.SWITCH, STARTING	1	25134-	
15	0-5610-02400	.RESISTOR	1	25134-	
16	0-5050-00015	.FUSE, 15A	5	25134-	
	0-5051-00000	.HOLDER, FUSE	5	25134-	
17	0-5420-00000	.SWITCH, FLASHER	1	25134-	
18	0-5410-02001	.SWITCH, LIGHTING	1	25181-	
19	0-5160-02400	.LAMP, HYDRAULIC OIL CHARGE	1	25134-	
20	1-17210-1151	.WIRING HARNESS	1	25268-	
21	0-5050-00040	.FUSE, 40A	1	25134-	
22	0-1000-00620	BOLT	4	25134-	
23	0-1100-00615	WASHER, SPRING	4	25134-	
24	0-1120-00616	WASHER	4	25134-	
25	0-5450-00000	SWITCH, H-L SPEED	1	25134-	
26	0-5161-02400	LAMP, H-L SPEED	1	25134-	

FIG. 711 ELECTRICAL SYSTEM (SERIAL NO. 25134-25267)



Serial No. 25242~





FIG NO. 711

INDEX NO.	PART NO.	DESCRIPTION	QTY	SERIAL NO. MST-2500	SERIAL NO.
1	1-19210-1410	WIRING HARNESS	1	25134-25267	
2	1-12210-1430	WIRE, EARTH	1	25134-*	
3	0-1200-01008	NUT	1	25134-*	
4	0-1100-01025	WASHER, SPRING	1	25134-*	
5	0-1120-01020	WASHER	1	25134-*	
6	1-21210-1210	HEAD LAMP ASS'Y, L.H.	1	25134-*	
7	1-21210-1230	.BULB, OUTER	1	25134-*	
8	1-21210-1240	.BULB, INNER	1	25134-*	
9	1-21210-1220	HEAD LAMP ASS'Y, R.H.	1	25134-*	
10	1-21210-1230	.BULB, OUTER	1	25134-*	
11	1-21210-1240	.BULB, INNER	1	25134-*	
12	0-5120-02400	LAMP ASS'Y, TURN SIGNAL	2	25134-*	
13	0-5600-02400	HORN	1	25134-*	
14	0-1200-00806	NUT	2	25134-*	
15	0-1100-00820	WASHER, SPRING	1	25134-*	
16	0-1120-00816	WASHER	2	25134-*	
17	1-13210-1230	REGULATOR ASS'Y	1	25134-*	
18	0-1200-00605	NUT	2	25134-*	
19	0-1100-00615	WASHER, SPRING	2	25134-*	
20	0-5510-02400	RELAY, HEATER	1	25134-*	
21	0-1200-00605	NUT	2	25134-*	
22	0-1100-00615	WASHER, SPRING	2	25134-*	
23	0-5520-02400	RELAY, FLASHER	1	25134-*	
24	0-1200-00605	NUT	1	25134-*	
25	0-1100-00615	WASHER, SPRING	1	25134-*	
26	1-23210-1511	SWITCH, OIL PRESSURE	1	25134-*	
	01-23210-1510	SWITCH, OIL PRESSURE	1	25134-25194	
27	0-5310-00024	SENSOR, ENGINE OIL PRESSURE	1	25134-25227	
	0-5310-01024	SENSOR, ENGINE OIL PRESSURE	1	25228-*	
28	0-5320-00024	SENSOR ENGINE WATER TEMPERATURE	1	25134-25227	

FIG NO. 711

INDEX NO.	PART NO.	DESCRIPTION	Q 'TY	SERIAL NO. MST-2500	SERIAL NO.
	0-5320-30024	SENSOR ENGINE WATER TEMPERATURE	1	25228-*	
29	1-29210-1560	SWITCH, PARKING BRAKE	1	25242-*	
30	1-12210-1450	WIRING HARNESS	1	25242-*	
31	0-1200-00605	NUT	1	25242-*	
32	1-28210-1510	UNIT, HST OIL TEMPERATURE	1	25242-*	
33	1-29210-1520	BRACKET	1	25242-*	
34	0-1000-00616	BOLT	2	25242-*	
35	0-1200-00605	NUT	2	25242-*	
36	0-1100-00615	WASHER, SPRING	2	25242-*	
37	0-1000-00814	BOLT	2	25242-*	
38	0-1100-00820	WASHER, SPRING	2	25242-*	
39	0-2720-02506	CLIP, LARGE	AR	25134-*	
	0-2720-01206	CLIP, SMALL	AR	25134-*	
40	0-1200-00605	NUT	AR	25134-*	
41	0-1100-00615	WASHER, SPRING	AR	25134-*	
42	0-2750-00000	CLIP	AR	25134-*	
43	0-2830-01520	TUBE, SPIRAL	AR	25134-*	
	0-2830-02420	TUBE, SPIRAL	AR	25134-*	
	0-2830-02920	TUBE, SPIRAL	AR	25134-*	
44	0-2800-00202	BAND	AR	25134-*	
	0-2800-00383	BAND	AR	25134-*	

FIG. 711A ELECTRICAL SYSTEM (SERIAL NO. 25268-)




FIG NO. :711A

INDEX NO.	PART NO.	DESCRIPTION	Q'TY	SERIAL NO. MST-2500	SERIAL NO.
1	1-19210-1411	WIRING HARNESS	1	25268-	
2	1-12210-1430	WIRE, EARTH	1	25134-	
3	0-1200-01008	NUT	1	25134-	
4	0-1100-01025	WASHER, SPRING	1	25134-	
5	0-1120-01020	WASHER	1	25134-	
6	1-21210-1210	HEAD LAMP ASS'Y, L.H.	1	25134-	
7	1-21210-1230	.BULB, OUTER	1	25134-	
8	1-21210-1240	.BULB, INNER	1	25134-	
9	1-21210-1220	HEAD LAMP ASS'Y, R.H.	1	25134-	
10	1-21210-1230	.BULB, OUTER	1	25134-	
11	1-21210-1240	.BULB, INNER	1	25134-	
12	0-5120-02400	LAMP ASS'Y, TURN SIGNAL	2	25134-	
13	0-5600-02400	HORN	1	25134-	
14	0-1200-00806	NUT	2	25134-	
15	0-1100-00820	WASHER, SPRING	1	25134-	
16	0-1120-00816	WASHER	2	25134-	
17	1-13210-1230	REGULATOR ASS'Y	1	25134-	
18	0-1200-00605	NUT	2	25134-	
19	0-1100-00615	WASHER, SPRING	2	25134-	
20	0-5510-02400	RELAY, HEATER	1	25134-	
21	0-1200-00605	NUT	2	25134-	
22	0-1100-00615	WASHER, SPRING	2	25134-	
23	0-5520-02400	RELAY, FLASHER	1	25134-	
24	0-1200-00605	NUT	1	25134-	
25	0-1100-00615	WASHER, SPRING	1	25134-	
26	1-23210-1511	SWITCH, OIL PRESSURE	1	25195-	
27	0-5310-01024	SENSOR, ENGINE OIL PRESSURE	1	25228-	
28	0-5320-30024	SENSOR ENGINE WATER TEMPERATURE	1	25228-	
29	1-29210-1560	SWITCH, PARKING BRAKE	1	25242-	

FIG NO. 711A

INDEX NO.	PART NO.	DESCRIPTION	Q 'TY	SERIAL NO. MST-2500	SERIAL NO.
30	1-12210-1450	WIRING HARNESS	1	25242-	
31	0-1200-00605	NUT	1	25242-	
32	1-28210-1510	UNIT,HST OIL TEMPERATURE	1	25242-	
33	1-29210-1520	BRACKET	1	25242-	
34	0-1000-00616	BOLT	2	25242-	
35	0-1200-00605	NUT	2	25242-	
36	0-1100-00615	WASHER, SPRING	2	25242-	
37	0-1000-00814	BOLT	2	25242-	
38	0-1100-00820	WASHER, SPRING	2	25242-	
39	0-2720-02506	CLIP, LARGE	AR	25134-	
	0-2720-01206	CLIP, SMALL	AR	25134-	
40	0-1200-00605	NUT	AR	25134-	
41	0-1100-00615	WASHER, SPRING	AR	25134-	
42	0-2750-00000	CLIP	AR	25134-	
43	0-2830-01520	TUBE, SPIRAL	AR	25134-	
	0-2830-02420	TUBE, SPIRAL	AR	25134-	
	0-2830-02920	TUBE, SPIRAL	AR	25134-	
44	0-2800-00202	BAND	AR	25134-	
	0-2800-00383	BAND	AR	25134-	

FIG. 715 BATTERY (SERIAL NO. 25134-25267)




FIG NO. 1715

INDEX NO.	PART NO.	DESCRIPTION	QTY	SERIAL NO. MST-2500	SERIAL NO.
1	0-5000-01200	BATTERY, N120	2	25134-*	
2	0-5010-00000	TERMINAL (+)	2	25134-*	
3	0-5011-00000	TERMINAL (-)	2	25134-*	
4	1-12210-1440	CABLE	1	25134-*	
5	1-12210-1420	WIRE, EARTH	1	25134-*	
6	0-1200-01008	NUT	1	25134-*	
7	0-1100-01025	WASHER, SPRING	1	25134-*	
8	0-1120-01020	WASHER	1	25134-*	
9	1-17210-1310	BOARD, BATTERY	2	25134-*	
10	1-17210-1320	HOLDER, BATTERY	1	25134-*	
11	0-1200-01008	NUT	2	25134-*	
12	0-1100-01025	WASHER, SPRING	2	25134-*	
13	1-17210-1330	COVER	1	25181-*	
14	1-17210-1340	HOLDER	1	25181-*	
15	1-14210-1350	BOLT	2	25181-*	
16	0-1120-00616	WASHER	2	25181-*	

FIG. 715A BATTERY AND BATTERY RELAY (SERIAL NO. 25268--)





FIG NO. 1715A


INDEX NO.	PART NO.	DESCRIPTION	Q'TY	SERIAL NO. MST-2500	SERIAL NO.
1	0-5000-01200	BATTERY, N120	2	25134-	
2	0-5010-00000	TERMINAL (+)	2	25134-	
3	0-5011-00000	TERMINAL (-)	2	25134-	
4	1-12210-1440	CABLE	1	25134-	
5	1-12210-1420	WIRE, EARTH	1	25134-	
6	0-1200-01008	NUT	1	25134-	
7	0-1100-01025	WASHER, SPRING	1	25134-	
8	0-1120-01020	WASHER	1	25134-	
9	1-17210-1310	BOARD, BATTERY	2	25134-	
10	1-17210-1320	HOLDER, BATTERY	1	25134-	
11	0-1200-01008	NUT	2	25134-	
12	0-1100-01025	WASHER, SPRING	2	25134-	
13	1-17210-1330	COVER	1	25181-	
14	1-17210-1340	HOLDER	1	25181-	
15	1-14210-1350	BOLT	2	25181-	
16	0-1120-00616	WASHER	2	25181-	
17	0-5540-12400	RELAY, BATTERY	1	25268-	
18	0-1050-00820	BOLT	2	25268-	
19	1-18210-1440	CABLE	1	25268-	
20	1-16210-1450	WIRE, EARTH	1	25268-	

FIG. 811 MARKS AND PLATES (ENGLISH)



INDEX NO.	PART NO.	DESCRIPTION	Q 'TY	SERIAL NO. MST-2500	SERIAL NO.
1	0-7050-10000	PLATE, NAME, FUEL	1	25134-	
2	0-7340-10000	PLATE, CAUTION, HYDRAULIC OIL	1	25134-	
3	0-7300-10000	PLATE, CAUTION STARTING AND TRAVELING	1	25134-	
4	0-7330-10000	PLATE, CAUTION, WARM-UP	1	25134-	
5	0-7320-10000	PLATE, CAUTION, NEUTRAL	1	25134-	
6	0-7310-10000	PLATE, CAUTION BEFORE OPERATING	1	25134-	
7	0-7120-02500	PLATE, MARK, MST-2500	1	25134-	
8	0-7100-00000	PLATE, MARK	2	25134-	
9	0-7110-00000	PLATE, MARK, MOROOKA	1	25134-	
10	0-7131-10000	PLATE, MARK, 10000KG	1	25134-	
11	0-7230-10000	PLATE, OPERATING, PARKING BRAKE	1	25134-	
12	0-7480-10000	PLATE, SAFETY, DOWNHILL	1	25134-	
13	0-7000-10000	PLATE, NAME, MOROOKA	1	25134-	
14	0-7010-12500	PLATE, NAME, SERIAL NO.	1	25134-	
15	0-7210-11000	PLATE, OPERATING, FORWARD	1	25134-	
16	0-7210-03000	PLATE, OPERATING, NEUTRAL	2	25134-	
17	0-7210-12000	PLATE, OPERATING, REVERSE	1	25134-	
18	0-7200-10000	PLATE, OPERATING, DUMP LEVER	1	25134-	
19	1-17210-1160	PLATE, CAUTION, MAIN SWITCH	1	25144-25267	
20	0-7240-10000	PLATE, OPERATING, MAIN SWITCH	1	25134-25267	
21	0-7250-10000	PLATE, OPERATING H-L SPEED SWITCH	1	25134-	
22	0-7060-10000	PLATE, NAME, ENGINE STOP	1	25134-	
23	0-7220-10000	PLATE, OPERATING, THROTTLE	1	25134-	

FIG. 901 TOOL



INDEX NO.	PART NO.	DESCRIPTION	Q 'TY	SERIAL NO. MST-2500	SERIAL NO.
	0-9000-00000	TOOL KIT	1	25134-25184	
	0-9000-00001	TOOL KIT	1	25185-	
1	0-9050-00000	.BOX, TOOL	1	25134-	
2	0-9105-04600	.WRENCH	1	25134-	
3	0-9100-00000	.WRENCH SET	1	25134-	
	0-9100-00709	..WRENCH	1	25134-	
	0-9100-00810	..WRENCH	1	25134-	
	0-9100-01113	..WRENCH	1	25134-	
	0-9100-01214	..WRENCH	1	25134-	
	0-9100-01719	..WRENCH	1	25134-	
	0-9100-02224	..WRENCH	1	25134-	
4	0-9150-00000	.WRENCH, FILTER	1	25134-	
5	0-9130-00200	.WRENCH, ADJUSTABLE	1	25134-	
6	0-9210-00150	.DRIVER, SCREW (+)	1	25134-	
7	0-9200-00200	.DRIVER, SCREW (-)	1	25134-	
8	0-9140-00800	.WRENCH	1	25134-	
9	0-9500-00000	.PUMP, GREASE	1	25134-	
	0-9501-00000	..CARTRIDGE, GREASE	1	25134-	
10	0-1020-01025	.BOLT, FOR PARKING BRAKE	2	25185-	
11	0-1020-01065	.BOLT, FOR PARKING BRAKE	2	25185-	
12	0-1130-01020	.WASHER, FOR PARKING BRAKE	2	25185-	
13	0-1001-01630	.BOLT, FOR PARKING BRAKE	4	25185-	
14	0-1130-01630	.WASHER, FOR PARKING BRAKE	4	25185-	

NUMERICAL INDEX

PART NO	F/NO	I/NO	PART NO	F/NO	I/NO	PART NO	F/NO	I/NO	PART NO	F/NO	I/NO
0-1000-00616	201	33	0-1000-31225	311	15	0-1100-00820	551A	6	0-1100-02051	301	4
0-1000-00616	711	34	0-1000-31235	101	2	0-1100-00820	701	3	0-1100-02051	301	7
0-1000-00616	711A	34	0-1000-31235	101	30	0-1100-00820	711	15	0-1100-02051	401	9
0-1000-00620	701	22	0-1000-31245	101	31	0-1100-00820	711A	36	0-1100-03075	301	22
0-1000-00620	701A	22	0-1000-31245	502	8	0-1100-00820	711A	15	0-1100-03075	311	30
0-1000-00620	701B	22	0-1000-31440	301	19	0-1100-00820	711A	38	0-1100-03690	311	30
0-1000-00614	711	37	0-1000-31445	502	7	0-1100-01025	101	14	0-1120-00616	201	35
0-1000-00614	711A	37	0-1000-32060	301	3	0-1100-01025	101	17	0-1120-00616	503	21
0-1000-00616	201	22	0-1000-32060	301	6	0-1100-01025	101	41	0-1120-00616	503A	21
0-1000-00616	201	41	0-1001-01630	901	13	0-1100-01025	101	52	0-1120-00616	503B	25
0-1000-00816	311	13	0-1001-31200	501	10	0-1100-01025	111	19	0-1120-00616	701	24
0-1000-00816	411	12	0-1010-01020	101	16	0-1100-01025	111	25	0-1120-00616	701A	24
0-1000-00816	551	5	0-1020-01025	901	10	0-1100-01025	111	33	0-1120-00616	701B	24
0-1000-00816	551A	5	0-1020-01065	901	11	0-1100-01025	121	8	0-1120-00616	715	16
0-1000-00820	111	4	0-1020-31025	501	12	0-1100-01025	201	15	0-1120-00616	715A	16
0-1000-00820	201	3	0-1020-32045	101	44	0-1100-01025	201	19	0-1120-00816	111	7
0-1000-00820	201	54	0-1021-31615	101	42	0-1100-01025	311	12	0-1120-00816	201	5
0-1000-00820	401	27	0-1050-00820	701A	2	0-1100-01025	401	14	0-1120-00816	201	26
0-1000-00820	411	5	0-1050-00820	701B	2	0-1100-01025	402	14	0-1120-00816	201	53
0-1000-00820	701	2	0-1050-00820	715A	18	0-1100-01025	402	25	0-1120-00816	201	55
0-1000-00825	111	3	0-1100-00615	121	15	0-1100-01025	402	30	0-1120-00816	411	6
0-1000-00825	201	25	0-1100-00615	201	34	0-1100-01025	501	37	0-1120-00816	411	14
0-1000-00830	201	11	0-1100-00615	503	20	0-1100-01025	551	17	0-1120-00816	701	4
0-1000-01020	121	7	0-1100-00615	503A	20	0-1100-01025	551A	19	0-1120-00816	711	16
0-1000-01020	201	18	0-1100-00615	503B	24	0-1100-01025	555	12	0-1120-00816	711A	16
0-1000-01020	551	16	0-1100-00615	701	23	0-1100-01025	711	4	0-1120-01020	101	15
0-1000-01020	551A	16	0-1100-00615	701A	23	0-1100-01025	711A	4	0-1120-01020	101	18
0-1000-01025	201	14	0-1100-00615	701B	23	0-1100-01025	715	7	0-1120-01020	111	34
0-1000-01025	311	11	0-1100-00615	711	19	0-1100-01025	715	12	0-1120-01020	121	9
0-1000-01025	555	11	0-1100-00615	711	22	0-1100-01025	715A	7	0-1120-01020	201	16
0-1000-01030	101	50	0-1100-00615	711	25	0-1100-01025	715A	12	0-1120-01020	201	20
0-1000-01030	111	31	0-1100-00615	711	36	0-1100-01230	101	4	0-1120-01020	402	15
0-1000-01035	111	17	0-1100-00615	711A	41	0-1100-01230	101	32	0-1120-01020	501	38
0-1000-01035	111	23	0-1100-00615	711A	19	0-1100-01230	201	49	0-1120-01020	551	18
0-1000-01035	401	12	0-1100-00615	711A	22	0-1100-01230	201	8	0-1120-01020	551A	20
0-1000-01035	402	13	0-1100-00615	711A	25	0-1100-01230	201	31	0-1120-01020	555	13
0-1000-01040	111	32	0-1100-00615	711A	36	0-1100-01230	201	46	0-1120-01020	711	13
0-1000-01050	402	32	0-1100-00615	711A	41	0-1100-01230	311	16	0-1120-01020	711A	5
0-1000-01225	201	7	0-1100-00820	111	6	0-1100-01230	401	18	0-1120-01020	715	8
0-1000-01225	201	30	0-1100-00820	201	4	0-1100-01230	401	21	0-1120-01020	715A	8
0-1000-01225	501	17	0-1100-00820	201	12	0-1100-01230	402	19	0-1120-01223	101	5
0-1000-01225	501	20	0-1100-00820	201	23	0-1100-01230	501	17	0-1120-01223	101	24
0-1000-01225	501	23	0-1100-00820	201	28	0-1100-01230	601	12	0-1120-01223	101	33
0-1000-01235	201	44	0-1100-00820	201	42	0-1100-01230	601	18	0-1120-01223	201	9
0-1000-01245	501	14	0-1100-00820	201	57	0-1100-01230	601	24	0-1120-01223	201	47
0-1000-01255	402	18	0-1100-00820	311	14	0-1100-01230	601	21	0-1120-01223	401	22
0-1000-01260	101	23	0-1100-00820	401	29	0-1100-01435	301	20	0-1120-01223	402	20
0-1000-01450	111	27	0-1100-00820	411	8	0-1100-01640	101	7	0-1120-01223	501	15
0-1000-01030	101	40	0-1100-00820	411	13	0-1100-01640	101	43	0-1120-01432	111	29
0-1000-01060	401	25	0-1100-00820	551	6	0-1100-02051	101	45	0-1120-01632	101	8

MST-2500

1

MST-2500

2

PART NO	F/NO	I/NO	PART NO	F/NO	I/NO	PART NO	F/NO	I/NO	PART NO	F/NO	I/NO
0-1200-03660	601	6	0-1200-31210	601	11	0-2220-00455	502	18	0-2231-00250	503A	26
0-1200-01020	901	12	0-1200-33024	301	21	0-2220-00460	502	10	0-2231-00250	503B	7
0-1200-01630	901	14	0-1200-33024	311	29	0-2220-00640	504	1	0-2231-00250	503B	30
0-1200-00605	121	14	0-1201-01008	402	28	0-2220-00655	501	26	0-2231-00280	503	2
0-1200-00605	503	19	0-1201-01210	401	17	0-2220-00670	501	39	0-2231-00280	503A	2
0-1200-00605	503A	19	0-1220-01006	401	3	0-2220-00680	504	2	0-2231-00280	503B	2
0-1200-00605	503B	23	0-1220-01006	402	33	0-2221-00410	502	9	0-2232-00200	503	2
0-1200-00605	711	18	0-1242-01200	401	23	0-2221-00410	502	13	0-2232-00200	503	8
0-1200-00605	711	21	0-1242-02000	401	8	0-2221-00420	502	13	0-2232-00225	503	8
0-1200-00605	711	24	0-1310-01080	201	37	0-2221-00430	502	9	0-2232-00225	503A	8
0-1200-00605	711	31	0-1350-00630	311	8	0-2221-00600	504	2	0-2232-00225	503B	8
0-1200-00605	711	35	0-1350-00830	311	8	0-2221-00600	504	6	0-2250-00470	501	24
0-1200-00605	711	40	0-1350-01035	311	26	0-2221-00650	501	40	0-2252-00620	501	7
0-1200-00605	711A	18	0-1360-00616	402	8	0-2230-00240	503	14	0-2253-00400	501	18
0-1200-00605	711A	21	0-2000-03135	311	10	0-2230-00240	503	15	0-2321-01272	502	2
0-1200-00605	711A	24	0-2000-03135	501	11	0-2230-00240	503A	14	0-2321-01272	502	3
0-1200-00605	711A	31	0-2000-03150	311	27	0-2230-00240	503A	15	0-2322-01205	502	2
0-1200-00605	711A	35	0-2000-03150	555	6	0-2230-00240	503B	18	0-2331-01281	502	4
0-1200-00605	711A	40	0-2000-03155	301	10	0-2230-00240	503B	19	0-2332-01212	502	1
0-1200-00806	111	5	0-2010-02411	503	25	0-2230-00260	503	22	0-2610-01259	502	6
0-1200-00806	201	27	0-2010-02411	503A	23	0-2230-00260	503A	22	0-2700-00012	121	5
0-1200-00806	201	52	0-2010-02411	503B	27	0-2230-00270	503B	26	0-2700-00012	121	12
0-1200-00806	201	56	0-2010-02414	555	4	0-2230-00270	503A	6	0-2700-10038	504	22
0-1200-00806	411	7	0-2010-02418	502	12	0-2230-00270	503B	6	0-2700-10056	501	12
0-1200-00806	711	14	0-2010-02418	503	13	0-2230-00280	503A	11	0-2700-10095	111	3
0-1200-00806	711A	14	0-2010-02418	503	17	0-2230-00280	503B	15	0-2700-10138	111	14
0-1200-01008	101	13	0-2010-02418	503A	17	0-2230-00290	503	9	0-2700-10165	111	13
0-1200-01008	101	51	0-2010-02418	503A	28	0-2230-00290	503	23	0-2710-00080	101	10
0-1200-01008	111	18	0-2010-02418	503B	21	0-2230-00290	503A	25	0-2710-00085	101	21
0-1200-01008	111	24	0-2010-02418	503B	32	0-2231-00210	503B	29	0-2710-00090	101	21A
0-1200-01008	401	13	0-2010-03524	501	3	0-2231-00210	503	3	0-2720-01206	711	101
0-1200-01008	401	26	0-2010-03524	504	8	0-2231-00210	503	4	0-2720-01206	711A	39
0-1200-01008	402	24	0-2030-03538	502	3	0-2231-00210	503A	5	0-2720-02506	121	39
0-1200-01008	501	29	0-2031-03511	555	5	0-2231-00210	503B	5	0-2720-02506	711	39
0-1200-01008	711	36	0-2040-03027	501	10	0-2231-00220	503	5	0-2720-02506	711A	39
0-1200-01008	711	3	0-2040-03027	501	9	0-2231-00220	503	3	0-2750-00000	711	42
0-1200-01008	711A	3	0-2040-03027	501	21	0-2231-00220	503	4	0-2750-00000	711A	42
0-1200-01008	715	6	0-2051-01825	101	27	0-2231-00220	503	7	0-2800-00202	121	17
0-1200-01008	715	11	0-2100-00645	504	29	0-2231-00220	503A	3	0-2800-00202	711	44
0-1200-01008	715A	6	0-2102-01035	504	20	0-2231-00220	503A	4	0-2800-00202	711A	44
0-1200-01008	101	11	0-2102-01040	504	10	0-2231-00220	503B	12	0-2800-00383	121	44
0-1200-01210	101	3	0-2102-01400	501	9	0-2231-00220	503B	4	0-2800-00383	501	17
0-1200-01210	101	25	0-2150-01048	121	1	0-2231-00230	503	16	0-2800-00383	502	51
0-1200-01210	201	48	0-2151-01085	121	4	0-2231-00230	503	5	0-2800-00383	711	27
0-1200-01210	201	45	0-2152-01060	121	11	0-2231-00250	503	7	0-2800-00383	711A	44
0-1200-01210	401	20	0-2220-00440	502	10	0-2231-00250	503	43	0-2830-01520	711	44
0-1200-01210	501	16	0-2220-00440	502	45	0-2231-00250	503	7	0-2830-01520	711A	43
0-1200-01411	111	28	0-2220-00455	502	22	0-2231-00250	503	10	0-2830-02420	121	16
0-1200-01613	101	6	0-2220-00455	502	15	0-2231-00250	503A	24	0-2830-02420	711	43

PART	NO	F/NO	I/NO	PART	NO	F/NO	I/NO	PART	NO	F/NO	I/NO	PART	NO	F/NO	I/NO
0-2830-02420	711A	43		0-4200-00400	502		25	0-4400-01005	504		16	0-5220-01024	701		5
0-2830-02920	711	43		0-4200-00600	501		30	0-4410-00202	503		12	0-5220-01024	701A		4
0-2830-02920	711A	43		0-4200-01000	504		15	0-4410-00202	503		26	0-5220-01024	701B		4
0-2840-02020	501	50		0-4200-01400	501		16	0-4410-00202	503A		10	0-5230-00024	701		11
0-2840-02020	502	26		0-4210-00202	503		16	0-4410-00202	503A		24	0-5230-00024	701A		9
0-3000-01046	402	21		0-4210-00202	503A		16	0-4410-00202	503B		10	0-5230-00024	701B		9
0-3000-01072	402	22		0-4210-00202	503A		27	0-4410-00202	503B		28	0-5240-20024	701		10
0-3011-01202	401	15		0-4210-00202	503B		14	0-4410-00404	502		14	0-5240-20024	701A		8
0-3100-11000	402	23		0-4210-00202	503B		20	0-5000-01200	715		1	0-5240-20024	701B		8
0-3100-11200	401	19		0-4210-00202	503B		31	0-5000-01200	715A		1	0-5310-00024	711		27
0-3101-11200	401	16		0-4210-00404	501		20	0-5010-00000	715		2	0-5310-01024	711		27
0-3111-11000	402	27		0-4210-00404	501		46	0-5010-00000	715A		2	0-5310-01024	711A		27
0-3130-01060	402	26		0-4210-00606	501		28	0-5011-00000	715		3	0-5320-00024	711		28
0-3220-06363	601	7		0-4210-00606	501		41	0-5011-00000	715A		3	0-5320-30024	711		28
0-3260-00663	402	5		0-4210-00606	504		4	0-5050-00015	701		16	0-5320-30024	711A		28
0-3260-00663	402	9		0-4220-00606	504		21	0-5050-00015	701A		16	0-5400-00000	701		14
0-3300-01218	401	5		0-4220-01010	504		11	0-5050-00015	701B		16	0-5400-00000	701A		14
0-3300-01218	402	11		0-4220-01414	501		2	0-5050-00040	701		21	0-5400-00000	701B		14
0-3300-02062	301	16		0-4300-00202	503		11	0-5050-00040	701A		21	0-5410-02000	701		18
0-3310-02572	311	4		0-4300-00202	503A		9	0-5050-00040	701B		21	0-5410-02001	701		18
0-3310-03090	311	22		0-4300-00202	503B		9	0-5051-00000	701		16	0-5410-02001	701A		18
0-3311-04020	301	12		0-4300-00404	501		19	0-5051-00000	701A		16	0-5410-02001	701B		18
0-3400-00000	311	32		0-4300-00404	501		25	0-5051-00000	701B		16	0-5420-00000	701		17
0-3400-00100	601	5		0-4300-00404	502		11	0-5120-02400	711		12	0-5420-00000	701A		17
0-3400-00100	601	9		0-4300-00404	502		19	0-5120-02400	711A		12	0-5420-00000	701B		17
0-3400-00100	601	16		0-4300-00606	501		42	0-5160-02400	701		13	0-5430-00000	701		8
0-3400-00170	402	2		0-4300-00606	504		8	0-5160-02400	701		19	0-5430-00000	701A		6
0-3500-01020	402	31		0-4310-00404	502		16	0-5160-02400	701A		13	0-5430-00000	701B		5
0-4000-00300	551A	17		0-4310-00404	502		23	0-5160-02400	701A		19	0-5450-00000	701		25
0-4000-00400	121	6		0-4310-00606	504		7	0-5160-02400	701B		13	0-5450-00000	701A		25
0-4000-00400	501	22		0-4320-00202	503		25	0-5160-02400	701B		19	0-5450-00000	701B		25
0-4000-00400	504	18		0-4320-00202	503A		13	0-5161-02400	701		26	0-5510-02400	711		20
0-4000-01000	551	15		0-4320-00202	503B		23	0-5161-02400	701A		26	0-5510-02400	711A		20
0-4000-01400	551A	16		0-4320-00202	503B		27	0-5170-02400	701		7	0-5520-02400	711		23
0-4100-00604	501	47		0-4320-00606	501		8	0-5170-02400	701A		5	0-5520-02400	711A		23
0-4100-01006	501	32		0-4320-00606	504		3	0-5170-02400	701B		5	0-5540-12400	715A		17
0-4100-01006	501	43		0-4360-00202	503B		12	0-5180-02403	701A		11	0-5600-02400	711		13
0-4120-00404	502	11A		0-4360-00404	501		48	0-5180-02403	701B		11	0-5600-02400	711A		13
0-4122-00402	503	13		0-4360-00606	501		31	0-5190-02403	701A		10	0-5610-02400	701		15
0-4122-00402	503	17		0-4360-01010	504		13	0-5190-02403	701B		10	0-5610-02400	701A		15
0-4122-00402	503A	17		0-4370-01010	501		4	0-5200-03024	701		9	0-5620-00000	701B		5
0-4122-00402	503B	28		0-4400-00202	503B		14	0-5200-70024	701A		9	0-6000-06207	311		3
0-4122-00402	503B	21		0-4400-00402	502		13	0-5200-70024	701B		7	0-6003-00210	311		21
0-4122-00402	503B	32		0-4400-00404	502		24	0-5210-10024	701		12	0-6003-00313	301		11
0-4122-00404	501	49		0-4400-00602	501		29	0-5210-70024	701		12	0-6100-00206	402		16
0-4122-00604	502	21		0-4400-00604	501		44	0-5210-70024	701A		12	0-6102-00204	402		12
0-4200-00200	503B	11		0-4400-00606	504		5	0-5210-70024	701B		12	0-6110-00205	401		6
0-4200-00400	502	20		0-4400-01004	504		17	0-5220-00724	701		6	0-7000-00000	801		13

MST-2500

5

MST-2500

6

PART NO	F/NO	I/NO	PART NO	F/NO	I/NO	PART NO	F/NO	I/NO	PART NO	F/NO	I/NO
0-7010-02500	801	14	0-9100-01719	901	3	1-1160-1210	551A	14	1-17210-1320	715	10
0-7010-12500	811	14	0-9100-02224	901	3	1-1160-1220	551	9	1-17210-1320	715A	10
0-7050-00000	801	1	0-9105-04500	901	2	1-1160-1230	551A	9	1-17210-1330	715	13
0-7050-10000	811	1	0-9130-00200	901	5	1-1170-1150	601	3	1-17210-1330	715A	13
0-7060-00000	801	22	0-9140-00600	901	8	1-12210-1110	701A	3	1-17210-1340	715	14
0-7060-10000	811	22	0-9150-00000	901	4	1-12210-1110	701B	3	1-17210-1340	715A	14
0-7100-00000	801	8	0-9200-00200	901	7	1-12210-1420	715	5	1-17330-0020	311	23
0-7100-00000	811	8	0-9210-00150	901	6	1-12210-1420	715A	5	1-17330-1130	311	23
0-7110-00000	801	9	0-9500-00000	901	9	1-12210-1430	711	2	1-17330-1140	311	24
0-7110-00000	811	9	0-9500-00000	901	9	1-12210-1430	711A	2	1-17410-1120	411	3
0-7120-02500	801	7	1-1140-1330	101	22	1-1210-1440	715	4	1-17670-1210	504	19
0-7120-02500	811	7	1-1150-1121	121	3	1-1210-1440	715A	4	1-18110-1110	101	1
0-7131-00000	801	10	1-1150-1131	121	2	1-1210-1450	711	30	1-18130-1110	111	15
0-7131-10000	811	10	1-11210-1110	701	5	1-1210-1450	711A	30	1-18130-1130	111	21
0-7200-00000	801	18	1-1130-0020	311	5	1-1230-0030	311	5	1-18130-1140	111	16
0-7200-10000	811	18	1-1130-1130	311	5	1-1230-1130	311	5	1-18130-1150	111	22
0-7210-01000	801	15	1-1130-1140	311	6	1-1230-1140	311	6	1-18130-1160	111	26
0-7210-02000	801	17	1-1130-1230	301	25	1-12410-0010	411	1	1-18210-1440	715A	19
0-7210-03000	801	16	1-11340-1130	311	7	1-12410-1110	411	1	1-18350-1130	311	25
0-7210-03000	811	16	1-11340-1140	311	9	1-12420-1110	401	1	1-18640-0010	601	14
0-7210-11000	811	15	1-11410-1120	411	2	1-12420-1120	401	2	1-18670-1320	501	23
0-7210-12000	811	17	1-11410-1210	411	4	1-12420-1130	401	4	1-18710-1320	601	15
0-7220-00000	801	23	1-11410-1610	411	10	1-12420-1131	401	4	1-18710-1330	601	19
0-7220-10000	811	23	1-11510-1210	201	32	1-12420-1140	401	7	1-18710-1340	601	22
0-7230-00000	801	11	1-11520-1131	201	10	1-12420-1150	401	10	1-19120-0010	111	1
0-7230-10000	811	11	1-11520-1170	201	40	1-12420-1160	401	11	1-19120-1120	111	1
0-7240-00000	801	20	1-11620-0020	503	1	1-12420-1230	402	4	1-19120-1310	111	9
0-7240-10000	811	20	1-11620-0020	503A	1	1-12420-1250	402	6	1-19120-1320	111	8
0-7250-00000	801	21	1-11620-0020	503B	1	1-12420-1260	402	7	1-19120-1340	111	11
0-7250-10000	811	21	1-11650-1160	555	2	1-12420-1270	402	10	1-19120-1350	111	12
0-7300-00000	801	3	1-11650-1170	555	8	1-12420-1280	402	17	1-19130-1120	111	20
0-7300-10000	811	3	1-11660-0020	551	12	1-12520-1320	201	21	1-19130-1230	111	30
0-7310-00000	801	6	1-11660-0020	551A	12	1-12520-1321	201	21	1-19140-0010	101	9
0-7310-10000	811	6	1-11660-1120	551	3	1-1310-1230	711	17	1-19140-1210	101	10
0-7320-00000	801	5	1-11660-1120	551A	3	1-13210-1230	711A	17	1-19140-1310	101	19
0-7320-10000	811	5	1-11660-1130	551	4	1-13670-1410	501	10	1-19140-1320	101	20
0-7330-00000	801	4	1-11660-1130	551A	4	1-14110-1110	101	47	1-19140-1410	101	11
0-7330-10000	811	4	1-11660-1140	551	7	1-14210-1350	715	15	1-19140-1420	101	12
0-7340-00000	801	2	1-11660-1140	551A	7	1-14210-1350	715A	15	1-19150-0011	121	1
0-7340-10000	811	2	1-11660-1150	551	8	1-14340-1130	311	7	1-19150-1111	121	1
0-7480-00000	801	12	1-11660-1150	551A	8	1-1540-0010	201	50	1-19160-1110	101	34
0-7480-10000	811	12	1-11660-1160	551	11	1-1540-1510	201	51	1-19160-1120	101	35
0-9000-00000	901	1	1-11660-1160	551A	11	1-16210-1450	715A	20	1-19160-1130	101	37
0-9000-00001	901	1	1-11660-1170	551	10	1-17210-1140	801	19	1-19160-1140	101	38
0-9050-00000	901	1	1-11660-1170	551A	10	1-17210-1150	701	20	1-19160-1150	101	39
0-9100-00000	901	3	1-11660-1180	551	12	1-17210-1150	701A	20	1-19160-1160	101	36
0-9100-00709	901	3	1-11660-1180	551A	12	1-17210-1151	701B	20	1-19160-1170	101	5
0-9100-00810	901	3	1-11660-1190	551	13	1-17210-1160	811	19	1-19210-1101	701	5
0-9100-01113	901	3	1-11660-1190	551A	13	1-17210-1310	715	9	1-19210-1102	701A	3
0-9100-01214	901	3	1-11660-1210	551	14	1-17210-1310	715A	9	1-19210-1103	701B	3

PART NO	F/NO	I/NO	PART NO	F/NO	I/NO	PART NO	F/NO	I/NO	PART NO	F/NO	I/NO
1-19210-1110	701	27	1-19520-1330	201	24	1-23210-1511	711A	26	1-29210-1560	711	29
1-19210-1110	701A	27	1-19520-1350	701	1	1-23420-1310	401	24	1-29210-1560	711A	29
1-19210-1410	711	1	1-19520-1350	701A	1	1-23710-1610	601	25			
1-19210-1411	711A	1	1-19520-1351	701B	1	1-23710-1620	601	26			
1-19310-1110	301	1	1-19610-0010	101	26	1-23710-1630	601	27			
1-19320-1110	301	5	1-19610-0020	101	28	1-26660-1111	551A	1			
1-19330-0010	301	8	1-19610-1310	101	27	1-28210-1510	711	32			
1-19330-0020	301	13	1-19610-1510	101	46	1-28210-1510	711A	32			
1-19330-1110	301	8	1-19620-0010	501	13	1-29210-1520	711	33			
1-19330-1120	301	9	1-19620-0011	501	13	1-29210-1520	711A	33			
1-19330-1130	301	13	1-19620-0030	501	34						
1-19330-1140	301	14	1-19620-0040	503	18						
1-19330-1150	301	15	1-19620-0040	503A	18						
1-19330-1160	301	18	1-19620-0040	503B	22						
1-19330-1210	301	23	1-19620-1310	501	35						
1-19330-1220	301	24	1-19630-0010	301	2						
1-19330-1240	301	17	1-19630-0011	301	2						
1-19340-0011	311	1	1-19650-0010	501	33						
1-19340-0012	311	1	1-19650-0010	555	1						
1-19340-1110	311	1	1-19650-1110	555	1						
1-19340-1111	311	1	1-19650-1120	555	5						
1-19340-1121	311	2	1-19650-1140	555	7						
1-19350-0010	311	19	1-19660-0010	551	1						
1-19350-0011	311	19	1-19660-0011	551A	1						
1-19350-1110	311	19	1-19660-1110	551	1						
1-19350-1120	311	20	1-19660-1230	551	2						
1-19350-1121	311	20	1-19660-1230	551A	2						
1-19350-1140	311	28	1-19670-1310	501	5						
1-19350-1180	311	31	1-19670-1320	501	27						
1-19350-1210	311	17	1-19670-1330	501	21						
1-19350-1211	311	17	1-19670-1340	501	9						
1-19350-1230	311	18	1-19710-1110	601	1						
1-19350-1400	311	29	1-19710-1140	601	2						
1-19410-0020	411	9	1-19710-1160	601	4						
1-19410-1310	411	11	1-19710-1310	601	8						
1-19410-1510	411	9	1-19710-1400	601	13						
1-19420-1210	402	1	1-21210-1210	711	6						
1-19420-1220	402	3	1-21210-1210	711A	6						
1-19510-1110	201	1	1-21210-1220	711	9						
1-19510-1230	201	29	1-21210-1220	711A	9						
1-19510-1310	201	36	1-21210-1230	711	7						
1-19520-1110	201	2	1-21210-1230	711A	10						
1-19520-1120	201	6	1-21210-1230	711A	7						
1-19520-1140	201	48	1-21210-1230	711A	10						
1-19520-1150	201	39	1-21210-1240	711	8						
1-19520-1160	201	43	1-21210-1240	711	11						
1-19520-1170	201	49	1-21210-1240	711A	8						
1-19520-1180	201	13	1-21210-1240	711A	11						
1-19520-1220	201	38	1-23210-1510	711	26						
1-19520-1320	201	17	1-23210-1511	711	26						

MST-2500

9

MST-2500

10